


Grex PPN65

1½" & 2½" Length Metal Connector Nailer

(Hc)

EXPLODED DIAGRAM



Grex PPN65

1½" & 2½" Length Metal Connector Nailer

PARTS LIST

No.	Part No.	Description
01	88006	Hex. Soc. Head Screw
02	66501	Deflector Washer
03	96121	O-Ring
04	66502	Deflector
05	99061	Hex. Soc. Head Screw
06	66551	Head Cap
07	96134	O-Ring
08	66544	Cap Gasket
09	66554	Head Valve Spring
10	66549	Head Valve Washer
11	66546	Head Valve
12	96135	O-Ring
13	96117	O-Ring
14	66550	Piston Ram Assembly
15	96127	O-Ring
16	96129	O-Ring
17	66552	Cylinder
18	66508	Bumper
19	66509	Safety Valve Spring
20	66510	Safety Valve Cap
21	96130	O-Ring
22	96131	O-Ring
23	66511	Safety Valve
24	96122	O-Ring
25	66512	Sequential Valve Spring
26	96126	O-Ring
27	66513	Sequential Firing Valve
28	96108	O-Ring
29	96119	O-Ring
30	66514	Sequential Valve Guide
31	66515	Safety A
32	91011	Hex. Soc. Head Screw
33	66548	Safety B
34	66516	Safety Spring Block
35	66517	Safety Spring

No.	Part No.	Description
36	96125	O-Ring
37	66518	Trigger Valve
38	96128	O-Ring
39	66519	Trigger Valve Spring
40	96010	O-Ring
41	66520	Trigger Valve Stem
42	96106	O-Ring
43	66521	Trigger Valve Guide
44	66522	Trigger Pin
45	66523	Trigger
46	96113	O-Ring
47	66525	Safety Guide
48	66555	Gun Body
49	66526	Bottom Cap Gasket
50	66527	Nose
51	99031	Hex. Soc. Head Screw
52	66529	Pusher Spring Bracket
53	66553	Pusher Assembly
54	66531	Pusher Roll Spring
55	66528	Safety Guide Spring Pin
56	66532	Belt Hook
59	94002	Air Plug
60	91002	Hex. Soc. Flat Head Screw
61	92006	Lock Nut
62	91040	Hex. Soc. Flat Head Screw
63	66547	Magazine
64	99060	Hex. Soc. Head Screw
65	66535	Pusher Stop
66	96111	O-Ring
67	66536	Rubber Sleeve
68	66537	Rear Magazine Pin
69	66543	Magazine Rail Plate
--	6500	Sequential Valve Assembly
--	6501	Safety Valve Assembly
--	6502	Trigger Valve Assembly